

DECUS NO.

8-540B

TITLE

**BPRINT** 

AUTHOR

Richard Rubinstein

COMPANY


University of California Irvine, California

DATE

March 30, 1972

SOURCELANGUAGE

PAL-8



6040

7325

BPRINT is a subroutine which enables a user's main program to emboss Braille on a modified ASR33 teletype. A complete one-cell Braille representation of the standard teletype character set is used, and Braille output codes may be modified easily if the user so desires.

```
BRAILLE PRINT PROGRAM
/RICHARD RUBINSTEIN
/UNIVERSITY OF CALIFORNIA, IRVINE
/NOVEMBER, 1971
/THIS ROUTINE PROVIDES BRAILLE PRINTOUT
ON CONSOLE TTY WITH BRAILLE MODIFICATIONS
ON ENTRY, AC=ASCII CHAR TO BE BRAILLED
PROUTINE PRESERVES MQ BUT NOT THE LINK
/RETURNS WITH AC= Ø
/PRIOR TO FIRST CALL, TTY MUST BE INITIALIZED WITH A TFL INSTRUCTION
/ALL NON-GRAPHIC CHARS, EXCEPT (CR) ARE TRANSMITTED TO TELETYPE, AS IS.
/(CR) GENERATES (CR)(LF)(LF)
/EXTRA (CR) (LF) (LF) SEQUENCES INSERTED AS NECESSARY IN LONG LINES
/INTERRUPT IS NOT MANIPULATED
TFL=
        6040
NL0003= 7325
```

00200	0000	BPRINT	Ø					
00201	0362	O. K. 1111	AND		N177		/FL 1414.7F 0.01FV	
00202	3375		DCA		CHAR		ELIMINATE PARITY	
00203	137.5						/SAVE CH. AC+0	
00204	7041		TAD		CHAR		GET CHAR	
			CIA					
00205	1361		TAD		NCR		/IS IT (CR)?	
00206	7650		SNA	CLA				
00207	5225		JMP		CR			
		-/						
00210	1375	81,	TAD		CHAR		/GET CHAR	
00211	1364		TAD		M 40			
00212	7710	•		CLA	שדויו		/CHAR < 40?	
00213	5220			CLA	V M = =			
			JMP		XMIT		/YES=-XMIT IT	
00214	1375		TAD		CHAR		/NO-GET CHAR	
00215	1367		TAD		M137		/CHAR > 137?	
00216	7750		SPA	SNA	CLA			
00217	5236		JMP		B2		/NO TRANSLATE IT	4
		1					MO IN MUSERIE II	
00220	1375	XMIT,	TAD		CHAR .		ACET GUAD	
00221	4303		JMS		T1		GET CHAR	
00222	5600			- 12 m			/XMIT IT	
00 22 2	2000	,	JMP	1	BPRINT		/RE TURN	
00007		/						
00223	1363	XCR,	TAD		NLF		/XM IT (LF) THEN (CR) SEQUENCE	
00224	4303		JMS		T1			
00225	1361	CR,	TAD		NCR		/XMIT (CR) SEQUENCE	
00226	4303		JMS		T1		THE TOTAL SERVE	
00227	1363		TAD		NLF			
00230	4303		JMS		T1			
00231	1363		TAD					
00232	4303				NLF			
			JMS		T1			
00233	1365		TAD		MD72		RESET LINE CHAR COUNT	
00234	3376		DCA		NCHAR			
00235	5600		JMP	I	BPRINT		/RETURN	
		/CHAR I	N RAM	VGF-	-XLATE	T		
00236	1375	B2,	TAD		CHAR	• '	/GET CH	
00237	1364	02,	TAD		M 40			-
00240	0366						/SUBTRACT 40	
			AND		N77		TRIM TO 6 BITS	
00241	7110			RAR			/TABLE DISPLACEMENT	
00242	1372		TAD		ATTAB			
00245	3374		DCA		TEMP			
00244	1774		TAD	I	TEMP			
00245	7430		SZL.				/L=0 => LEFT HALF	
00246	5252	•	JMP		B3		RIGHT HALF =- OK	
00247	7012		RTR					
00250	7012		RTR				GET LEFT HALF	
00251								
	7012	n 7	RTR					
00252	0366	в3,	AND		N77		/ISOLATE RESULT	
00253	3375		DCA		CHAR		/SAVE	
00254	1375		TAD		CHAR		/TABLE ENTRY	
00255	7012		RTR					
00256	7010		RAR					
00257	Ø 37 1		AND		N7		/1ST CHAR	
00260	1373		TAD		ACTAB		- LOT OT AR	
00261	3374		DGA				/07+0 +000	
00262	1774				TEMP		CTAB ADDR	
				I	TEMP			
00263	4303		JMS		T1			
00 26 4	1375		TAD	1	CHAR			
00265	0371		AND	,	N7		/2ND CHAR	
						2	· ·	

```
00266
        1373
                         TAD
                                  ACTAB
00267
        3374
                        DCA
                                  TEMP
00270
        1774
                         TAD I
                                  TEMP
00271
        4303
                        JMS
                                  T1
00272
        7325
                        NL0003
                                                    /INCR LINE CHAR COUNT BY 3
00273
        1376
                        TAD
                                  NCHAR
00274
        3376
                        DCA
                                  NCHAR
00275
        1376
                        TAD
                                  NCHAR
00276
        7650
                        SNA CLA
                                                    /LINE FULL?
00277
        5223
                        JMP
                                  XCR
                                                    /YES--GEN (LF)(CR)(LF)(LF)
00300
        1370
                        TAD
                                 NSP
                                                    /NO == PROCEED
00301
        4303
                        JMS
                                  T1
                                                    /XMIT (SPACE)
00302
        5600
                        JMP I
                                 BPRINT
                                                    /RETURN
00303
               T1,
        0000
                                                    /TYPE ONE CHAR
00304
        6041
                        TSF
                                                    /TTY PTR READY?
00305
        5304
                        JMP
                                 . -1
                                                    /NO-=WAIT
00306
        6046
                        TLS
                                                    /XMIT CHAR
00307
        7200
                        CLA
00310
       5703
                        JMP I
                                 T1
                                                    / RETURN
                   /TRANSLATION TABLE
                   /AS READ, VALUE BRAILLE "BITS," FROM TOP, 4 2 1
    00311
            0075
                   TTAB.
                            0075
                                                        /(SPACE),!
    00312
            0217
                            0217
                                                        111,#
    00313
           4335
                            4335
                                                        /(DOLLAR),%
    00314
           4710
                            4710
                                                        18,1
    00315
           7337
                            7337
                                                        16,7
    00316
            0415
                            0415
                                                        14,+
    00317
            0111
                            0 11 1
                                                        / (COM MA) . -
   00320
           0514
                            0514
                                                        1.1
    00321
            1320
                            1320
                                                        10.1
   00322
            3022
                            3022
                                                        12,3
    00323
           2321
                            2321
                                                        14,5
    00324
            3233
                            3233
                                                        16,7
    00325
           3112
                            3112
                                                        18.9
    00326
           0603
                            0603
                                                        1: .:
    00327
           6163
                            6163
                                                        14,=
   00330
            4516
                            4516
                                                        17,3
   00331
           6540
                            6540
                                                        10, A
   00332
           6044
                            6044
                                                        /B,C
   00333
           4642
                            4642
                                                        /D.E
   00334
           6466
                            6466
                                                        /F,G
   00335
           6224
                            6224
                                                        /H. I
   00336
           2650
                            2650
                                                        1 J. K
   00337
           7054
                            7054
                                                        /L,M
   00340
           5652
                            5652
                                                        /N. 0
   00341
           7476
                            7476
                                                        /P,Q
   00342
           7234
                            7234
                                                        /R,S
   00343
           3651
                            3651
                                                       /T,U
   00344
           7127
                            7127
                                                       IV.W
   00345
          5557
                           5557
                                                       / X. Y
   00346
           5325
                            5325
                                                       12,0
   00347
           4167
                           4167
                                                       11,3
   00350
           077.7
                           0777
                                                       14,4
```

```
BRAILLE EQUIVALENT CHARACTERS
00351
              CTAB,
        0240
                        240
                                                   /(SPACE)
                                                                      0
00352
        0305
                        305
                                                   1E
                                                                      1
00353
       0316
                        516
                                                                      2
                                                   /N
00354
       0301
                        301
                                                                      3
                                                   /A
00355
       0314
                                                   16
                        314
                                                                      4
00356
       0303
                        303
                                                   /C
                                                                      5
00357
       0307
                        307
                                                   1G
                                                                      6
00360
       0310
                        310
                                                   /H
                                                                      7
00361
       0015
                        15
              NCR.
                                                   /(CR), PARITY TRIMMED
00362
       Ø177
              N177,
                       177
              NLF,
                        212
00363
        0212
                                                   /(LF)
00364
       7740
              M40.
                        -40
00365
       767Ø
              MD72,
                        -110
                                                   /RESET VAL FOR NCHAR =-72(10)
00366
       0077
                       77
              N77,
00367
       7641
              M137,
                        -137
                       240
00370
       0240
              NSP.
                                                   /ASCII SPACE
00371
       0007
              N7,
                        7
              ATTAB,
                        TTAB
00372
       0311
00373
                        CTAB
       0351
              ACTAB,
       0374
              TEMP=
       0375
              CHAR=
                        . +1
       0376
              NCHAR =
                        . +2
```

ACTAB	Ø373
ATTAB	0372
BPRINT	0200
81	0210
B2	0236
B3	0252
CHAR	0375
CR	Ø225
	0351
CTAB	
MD 72	0365
M1 37	0367
M40	0364
NCHAR	0376
NCR	0361
NLF	0363
NL 0003	7325
NSP	0370
N177	0362
N-7	0371
N77	0366
TEMP	0374
TFL	6040
TTAB	0311
T1	0303
XCR	0223
XMIT	0220
VIA 1	DECE

